

Indicates change from last listing 6.6.08	CURT T-CONNECTOR APPLICATION GUIDE									
	MAKE/MODEL	MODEL TYPE	YEARS	PART #	TYPE	INSTALL TIME	ELEC. SYSTEM	MINIMUM CONVERTER TYPE	WIRE LOCATION	OLD CODE
	ACURA									
	CL SERIES	ALL	1997-2003	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	P3	9
	INTEGRA	ALL	1994-2001	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	P3	9
	MDX	ALL	2001-2006	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	S3	9
	RDX	ALL	2007-2007	56008	T-CONNECTOR	25	3W	C3	P3	7
	RL SERIES	ALL	1996-2001	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	P3	9
	SLX	ALL	1996-1999	55339	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C1	S5	9
	TL SERIES	ALL	1996-2003	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	P3	9
	TSX	Full Size ALL	2006-2008	55502	T-CONNECTOR	10	3W	C1	P3	9
	BUICK									
	ENCLAVE	ALL	2008-2008	56027	T-CONNECTOR	10	2W	N/A	P1,P2	
		w/Factory 7-way	2008-2008	55384	T-CONNECTOR	10	2W	N/A	S5	4,10
	RAINIER	w/Factory 7-way	2004-2008	55384	T-CONNECTOR	10	2W	N/A	S6	4,10
	RENDEZVOUS	ALL	2002-2007	55383	T-CONNECTOR	20	2W	N/A	S1,S2	
	ROADMASTER	ALL	1991-1996	55347	T-CONNECTOR	10	2W	N/A	P3,P4	
	ROADMASTER ESTATE WAGON	ALL	1991-1996	55352	T-CONNECTOR	10	2W	N/A	P3,P4	
	TERRAZA	ALL	2005-2007	55536	T-CONNECTOR	15	2W	N/A	S1,S2	
	CADILLAC									
	ESCALADE	w/Factory 7-way	2002-2008	55384	T-CONNECTOR	5	2W	N/A	S6	4,10
		Old Body Style	1999-2000	55319	T-CONNECTOR	5	2W	N/A	S7	
	ESCALADE ESV	w/Factory 7-way	2003-2008	55384	T-CONNECTOR	5	2W	N/A	S6	4,10
	ESCALADE EXT	w/Factory 7-way	2002-2008	55384	T-CONNECTOR	5	2W	N/A	S6	4,10
	CHEVROLET PASSENGER & WAGON									
	CAPRICE	ALL	1991-1996	55347	T-CONNECTOR	10	2W	N/A	P3,P4	
	CAPRICE ESTATE WAGON	ALL	1991-1996	55352	T-CONNECTOR	10	2W	N/A	P3,P4	
	COBALT	2-DR	2005-2008	55432	T-CONNECTOR	15	2W	N/A	P1,P2	
		4-DR	2005-2008	55434	T-CONNECTOR	10	2W	N/A	P1,P2	
		SS 2-DR	2005-2008	55432	T-CONNECTOR	15	2W	N/A	P1,P2	
		SS 4-DR	2005-2008	55434	T-CONNECTOR	10	2W	N/A	P1,P2	
	IMPALA SS	ALL	1994-1996	55347	T-CONNECTOR	10	2W	N/A	P3,P4	
	MALIBU	ALL Except LTZ	2008-2008	56027	T-CONNECTOR	10	2W	N/A	P1,P2	
		ALL	2004-2007	56013	T-CONNECTOR	20	2W	N/A	P1,P2	
	CHEVROLET VAN & SPORT UTILITY VEHICLE									
	ASTRO	ALL	1995-2005	55411	T-CONNECTOR	15	2W	N/A	S4	
	AVALANCHE	w/Factory 7-way	2002-2008	55384	T-CONNECTOR	5	2W	N/A	S6	4,10
	BLAZER	Full Size ALL	1992-1994	55319	T-CONNECTOR	5	2W	N/A	S6	
			1985-1991	55312	T-CONNECTOR	5	2W	N/A	S1,S2	
			1973-1984	55311	T-CONNECTOR	5	2W	N/A	S1,S2	
	BLAZER S-10 Downsize	2-DR	1984-1991	55318	T-CONNECTOR	20	2W	N/A	S6	
	BLAZER S10/S15		1995-2002	55411	T-CONNECTOR	15	2W	N/A	S7	
	EQUINOX	ALL	2007-2008	56012	Replacement OEM Tow Package Wiring Harness (4-flat)	15	2W	N/A	S3	
			2005-2006	55560	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C3	S3	9
	EXPRESS	ALL	2003-2008	55540	T-CONNECTOR	20	2W	N/A	S3,S4	
			2000-2002	55377	T-CONNECTOR	10	3W	C1	S3,S4	9
			1996-1999	55335	T-CONNECTOR	20	3W	C1	S3,S4	9
		w/Factory 4-flat	2003-2003	55240	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S4	11
			1996-2002	55240	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S4	11
	G-SERIES VAN	ALL	1987-1995	55338	T-CONNECTOR	10	2W	N/A	S1,S2	
	HHR	ALL	2006-2008	55432	T-CONNECTOR	15	2W	N/A	S3,S4	
	LUMINA APV VAN	ALL	1993-1996	55337	T-CONNECTOR	20	2W	N/A	S1,S2	9
	SUBURBAN	New Body w/Amber Turn Signals	2000-2008	55384	T-CONNECTOR	5	2W	N/A	S6	4,10

Curt Manufacturing 2008 T-Connector Applications

	Old Body Style	1992-1999	55319	T-CONNECTOR	5	2W	N/A	S6	
	ALL	1985-1991	55312	T-CONNECTOR	5	2W	N/A	S5	
		1973-1984	55311	T-CONNECTOR	5	2W	N/A	S5	
TAHOE	New Body w/Amber Turn Signals	2000-2008	55384	T-CONNECTOR	5	2W	N/A	S6	4,10
	Old Body Style	1995-2000	55319	T-CONNECTOR	5	2W	N/A	S6	
TRACKER	ALL	1999-2004	55372	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C1	S1,S2	9
TRAILBLAZER	w/Factory 7-way	2002-2008	55384	T-CONNECTOR	5	2W	N/A	S7	4,10
UPLANDER	ALL	2005-2007	55536	T-CONNECTOR	15	2W	N/A	S1,S2	
VENTURE	ALL	1997-2005	55355	T-CONNECTOR	10	3W	C1	S3	9
CHEVROLET COMPACT TRUCK									
COLORADO	ALL w/o Factory 7-way	2004-2008	55510	T-CONNECTOR	10	3W	C1	T3	9
	w/Factory 7-way	2008-2008	55384	T-CONNECTOR	5	2W	N/A	T4	10
S-10 PICKUP	ALL	1998-2004	55359	T-CONNECTOR	5	2W	N/A	T3	
		1985-1997	55312	T-CONNECTOR	5	2W	N/A	T3	
	2-DR	1992-1994	55413	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S3	
CHEVROLET PICKUP FULL-SIZE									
C/K SERIES PICKUP	ALL Except 88-91 Crew Cab	1988-2000	55315	T-CONNECTOR	5	2W	N/A	T3	
	ALL	1985-1987	55312	T-CONNECTOR	5	2W	N/A	T3	
		1973-1984	55311	T-CONNECTOR	5	2W	N/A	T3	
C/K SERIES PICKUP	Crew Cab, Old Body Style	1988-1991	55312	T-CONNECTOR	5	2W	N/A	T3	
SILVERADO	Classic & New Body	1999-2008	55515	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	T3 OR T4	
	Classic & New Body w/Factory 7-way	2007-2008	55384	T-CONNECTOR	5	2W	N/A	T3	4,10
		2007-2007	56000	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T3	
	w/Factory 7-way	1999-2006	55384	T-CONNECTOR	5	2W	N/A	T3	4,10
		1999-2006	56000	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T3	
CHRYSLER									
300	ALL	2005-2007	55534	T-CONNECTOR	10	2W	N/A	P3,P4	
300C	ALL	2005-2007	55546	T-CONNECTOR	15	3W	C3	P3,P4	9
300M	ALL	1999-2004	55364	T-CONNECTOR	15	3W	C1	P1,P2	9
ASPEN	ALL	2007-2008	55597	T-CONNECTOR	25	3W	C3	S1,S2	9
CONCORDE	ALL	1998-2002	55364	T-CONNECTOR	15	3W	C1	P1,P2	9
INTREPID	Canada Only	1998-2004	55364	T-CONNECTOR	15	3W	C1	P1,P2	9
LHS	ALL	1999-1999	55364	T-CONNECTOR	15	3W	C1	P1,P2	9
PACIFICA	ALL	2004-2008	55530	T-CONNECTOR	25	3W	C3	S1,S2	7
PT CRUISER	ALL	2000-2007	55532	T-CONNECTOR	20	3W	C3	P1,P2	7
TOWN & COUNTRY	ALL	2008-2008	56019	T-CONNECTOR	N/A	2W	C3	S1,S2	
		2004-2007	55537	T-CONNECTOR	20	2W	N/A	S1,S2	
		2001-2003	55376	T-CONNECTOR	15	3W	C1	S1,S2	9
		1996-2000	55334	T-CONNECTOR	20	3W	C1	S1,S2	9
		1991-1995	55323	T-CONNECTOR	10	2W	N/A	S1,S2	
		1989-1990	55493	T-CONNECTOR	10	2W	?	S1,S2	
VOYAGER	ALL	2001-2003	55376	T-CONNECTOR	15	3W	C1	S1,S2	9
DODGE PASSENGER & WAGON									
AVENGER	ALL	2008-2008	56028	T-CONNECTOR	30	3W	C3	P1,P2	
CALIBER	ALL	2008-2008	56019	T-CONNECTOR	30	2W	C3	S1,S2	
		2007-2007	55050	T-CONNECTOR	30	3W	C3	P1,P2	7
CHARGER	ALL	2006-2008	55534	T-CONNECTOR	10	2W	N/A	P3,P4	
INTREPID	ALL	1998-2004	55364	T-CONNECTOR	15	3W	C1	P1,P2	9
MAGNUM	ALL	2005-2008	55562	T-CONNECTOR	30	3W	C3	P1,P2	7
DODGE VAN & SPORT UTILITY VEHICLE									
CARAVAN	ALL	2004-2007	55537	T-CONNECTOR	20	2W	N/A	S1,S2	
		2001-2003	55376	T-CONNECTOR	15	3W	C1	S1,S2	9
		1996-2000	55334	T-CONNECTOR	20	3W	C1	S1,S2	9
		1991-1995	55323	T-CONNECTOR	10	2W	N/A	S1,S2	
		1989-1990	55493	T-CONNECTOR	10	2W	?	S1,S2	
DURANGO	ALL	2004-2008	55597	T-CONNECTOR	25	3W	C3	S1,S2	9
		1998-2003	55334	T-CONNECTOR	20	3W	C1	S1,S2	9
	w/Factory 7-way	2000-2007	55381	T-CONNECTOR	5	2W	N/A	S1,S2	4,10
GRAND CARAVAN	ALL	2008-2008	56019	T-CONNECTOR	30	2W	C3	S1,S2	
		2004-2007	55537	T-CONNECTOR	20	2W	N/A	S1,S2	

Curt Manufacturing 2008 T-Connector Applications

		2001-2003	55376	T-CONNECTOR	15	3W	C1	S1,S2	9
		1996-2000	55334	T-CONNECTOR	20	3W	C1	S1,S2	9
		1991-1995	55323	T-CONNECTOR	10	2W	N/A	S1,S2	
NITRO	ALL	2007-2008	55027	T-CONNECTOR	15	3W	C1	S1,S2	9
SPRINTER	w/Factory 7-way	2003-2006	55381	T-CONNECTOR	5	2W	N/A	S3,S4	4,10
VAN, FULL SIZE	w/Factory 7-way	2001-2003	55381	T-CONNECTOR	5	2W	N/A	S5	4,10
	ALL	1999-2000	55368	Replacement OEM Tow Package Wiring Harness (4-flat)	5	2W	N/A	S5	
VAN, B-SERIES, FULL SIZE	ALL	1993-1998	55328	T-CONNECTOR	5	2W	N/A	S7	
DODGE COMPACT PICKUP									
DAKOTA	ALL	2003-2008	55323	T-CONNECTOR	10	2W	N/A	T1,T2	
		1995-2003	55329	T-CONNECTOR	5	2W	N/A	T3,T5	6
		1987-1994	55317	T-CONNECTOR	5	2W	N/A	T3,T5	
	w/Factory 7-way	2000-2008	55381	T-CONNECTOR	5	2W	N/A	T3,T5	4,10
		1995-2008	56001	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T3,T5	
DODGE PICKUP FULL-SIZE									
RAM 1500	ALL	2002-2005	55504	T-CONNECTOR	10	3W	C1	T3,T5	9
		1995-2001	55329	T-CONNECTOR	5	2W	N/A	T3,T5	6
	w/Factory 7-way	1995-2008	56001	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T3,T5	
RAM 2500/3500	ALL	2003-2005	55504	T-CONNECTOR	10	3W	C1	T3,T5	9
		2002-2002	55329	T-CONNECTOR	5	2W	N/A	T3,T5	6
	w/Factory 7-way	1995-2008	56001	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T3,T5	
RAM, PICKUP, FULL SIZE	w/Factory 7-way	2000-2008	55381	T-CONNECTOR	5	2W	N/A	T3,T5	4,10
	ALL	1994-1994	55317	T-CONNECTOR	5	2W	N/A	T1,T2	
		1986-1993	55317	T-CONNECTOR	5	2W	N/A	T1,T2	
RAMCHARGER	ALL	1986-1993	55317	T-CONNECTOR	5	2W	N/A	S5,S7	
FORD PASSENGER & WAGON									
EDGE	ALL	2007-2008	56014	T-CONNECTOR	10	2W	N/A	S1,S2	
ESCORT	4-DR	1997-1999	55344	T-CONNECTOR	10	2W	N/A	P1,P2	
ESCORT ZX2	ALL	1998-2003	55344	T-CONNECTOR	10	2W	N/A	P1,P2	
		1973-1979	55301	T-CONNECTOR	5	2W	N/A	T3	
FIVE HUNDRED	ALL	2005-2007	55587	T-CONNECTOR	10	2W	N/A	P3,P4	
FOCUS	ALL	2008-2008	56014	T-CONNECTOR	10	2W	N/A	P1,P2	
FOCUS WAGON	Built before 11/02	2000-2003	55344	T-CONNECTOR	10	2W	N/A	P1,P2	
LTD CROWN VICTORIA	ALL	1992-1997	55326	T-CONNECTOR	20	2W	N/A	P3,P4	
MUSTANG	ALL Except Cobra SVT 99-04	1994-2004	55326	T-CONNECTOR	20	2W	N/A	P3,P4	
TAURUS	ALL	2008-2008	56015	T-CONNECTOR	20	2W	N/A	P3,P4	
		2000-2003	55375	T-CONNECTOR	10	2W	N/A	P3,P4	
	ALL Including SHO	1996-1999	55333	T-CONNECTOR	10	3W	C1	P3,P4	9
		1992-1995	55327	T-CONNECTOR	10	2W	N/A	P3,P4	
FORD VAN & SPORT UTILITY VEHICLE									
BRONCO	Full Size	1992-1996	55350	T-CONNECTOR	5	2W	N/A	S6	
		1989-1991	55303	T-CONNECTOR	5	2W	N/A	S5,S7	
		1987-1988	55302	T-CONNECTOR	5	2W	N/A	S5	
		1980-1986	55313	T-CONNECTOR	5	2W	N/A	S6	
ECONOLINE	ALL	2004-2007	56020	T-CONNECTOR	15	2W	N/A	S1,S2	
		1995-2003	55344	T-CONNECTOR	10	2W	N/A	S1,S2	
		1992-1994	55343	T-CONNECTOR	10	3W	C1	S1,S2	9
ESCAPE	ALL Including Hybrid	2008-2008	56014	T-CONNECTOR	10	2W	N/A	S1,S2	
		2005-2007	55568	T-CONNECTOR	10	3W	C1	S1,S2	9
		2000-2003	55343	T-CONNECTOR	10	3W	C1	S1,S2	9
	w/Tow Package	2001-2004	55255	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S3	11
EXCURSION	ALL	2000-2003	55344	T-CONNECTOR	10	2W	N/A	S1,S2	
EXPEDITION	ALL	1997-2003	55344	T-CONNECTOR	10	2W	N/A	S1,S2	
	w/Factory 4-flat	2000-2002	55250	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S5	11
		1997-1999	55249	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S5	11
EXPLORER	w/Tow Package	2002-2005	55251	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S7	11
	w/Factory 4-flat	1995-2001	55241	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S5	11
EXPLORER	2-DR Sport	2001-2003	55344	T-CONNECTOR	10	2W	N/A	S1,S2	
EXPLORER	4-DR	2002-2003	55344	T-CONNECTOR	10	2W	N/A	S1,S2	
		2001-2001	55345	T-CONNECTOR	25	3W	C3	S1,S2	7

Curt Manufacturing 2008 T-Connector Applications

EXPLORER	ALL	1995-2000	55345	T-CONNECTOR	25	3W	C3	S1,S2	7	
		1991-1994	55324	T-CONNECTOR	20	2W	N/A	S1		
FREESTAR	ALL	2004-2007	55545	T-CONNECTOR	25	2W	N/A	S1,S2	7	
		2004-2007	55545-RK	Relay Kit		N/A	N/A	N/A		
FREESTYLE	ALL	2005-2007	55587	T-CONNECTOR	10	2W	N/A	S1,S2		
WINDSTAR	Built after 11/02	2003-2003	55525	T-CONNECTOR	25	3W	CL	S1,S2	7,8	
	Built before 11/02	1999-2003	55366	T-CONNECTOR	25	3W	CL	S1,S2	7,8	
	ALL	1995-1998	55346	T-CONNECTOR	20	3W	C1	S1,S2	9	
FORD COMPACT PICKUP										
RANGER	ALL	2000-2003	55344	T-CONNECTOR	10	2W	N/A	T1,T2		
		1993-1999	55325	T-CONNECTOR	5	3W	C1	T3	9	
		1986-1992	55314	T-CONNECTOR	5	2W	N/A	T1,T2		
	w/Factory 4-flat	1998-1999	55241	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	T3	11	
FORD PICKUP FULL-SIZE										
F-150	ALL	2005-2007	56031	Replacement OEM Tow Package Wiring Harness (4-flat)	10	2W	N/A	T3		
		2004-2005	55551	T-CONNECTOR	10	2W	N/A	T3	4,10	
	Mfg. 1/96-2004	1997-2004	55256	T-CONNECTOR	5	2W	N/A	T3	10	
	w/Factory 4-flat (Mfg. 1/96-10/96)	1997-1997	55249	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	T3	11	
	New Body Style w/Factory 7-way	2004-2008	56000	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T3		
F-150 HERITAGE	Old Body Style w/Factory 4-flat	2004-2004	55028	Upgrade Kit (Adds 6-way to 4-flat)	5	N/A	N/A	T3	14	
		2004-2004	55242	Replacement OEM Tow Package Wiring Harness (7-way)	5	N/A	N/A	T1,T2	14	
	Old Body Style w/Factory 7-way	2004-2004	56000	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T1,T2		
F-150 FLARESIDE	Flareside Only	1997-2003	55344	T-CONNECTOR	10	2W	N/A	T1,T2		
F-150 HERITAGE FLARESIDE	Heritage Flareside Only	2004-2004	55344	T-CONNECTOR	10	2W	N/A	T1,T2		
F-150 SUPERCREW		2000-2003	55344	T-CONNECTOR	10	2W	N/A	T1,T2		
F-250 LIGHT DUTY	w/Factory 4-flat	1997-2003	55028	Upgrade Kit (Adds 6-way to 4-flat)	5	N/A	N/A	T3	14	
		1997-2003	55242	Replacement OEM Tow Package Wiring Harness (7-way)	5	N/A	N/A	T3	14	
	ALL	1997-2001	55256	T-CONNECTOR	5	2W	N/A	T3	10	
	w/Factory 4-flat	1997-1997	55249	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	T3	11	
	w/Factory 7-way	1997-2003	56000	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T1,T2		
F-250 & F-350 SUPER DUTY	ALL	2005-2007	56032	T-CONNECTOR	10	2W	N/A	T3		
	w/Factory 4-flat	2002-2004	55265	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	T4	11	
		1999-2001	55247	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	T3	11	
		1999-2001	55243	Replacement OEM Tow Package Wiring Harness (7-way)	5	N/A	N/A	T1,T2	14	
		1999-2001	55029	Upgrade Kit (Adds 6-way to 4-flat)	5	N/A	N/A	T3	14	
	ALL	1997-1997	55316	T-CONNECTOR	5	2W	N/A	T3		
	w/Factory 7-way	1999-2008	56000	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T1,T2		
F-450 & F-550 SUPER DUTY	w/Factory 4-flat	1999-2001	55029	Upgrade Kit (Adds 6-way to 4-flat)	5	N/A	N/A	T3	14	
		1999-2001	55243	Replacement OEM Tow Package Wiring Harness (7-way)	5	N/A	N/A	T1,T2	14	
	w/Factory 7-way	1999-2008	56000	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T1,T2		
F-100, F-150, F-250, F-350	ALL	1987-1996	55316	T-CONNECTOR	5	2W	N/A	T3		
F-SERIES	ALL	1980-1986	55313	T-CONNECTOR	5	2W	N/A	T3		
GMC VAN & SPORT UTILITY VEHICLE										
ACADIA	w/Factory 7-way	2007-2008	55384	T-CONNECTOR	5	2W	N/A	S5	4,10	
BLAZER	Full Size	1973-1984	55311	T-CONNECTOR	5	2W	N/A	S1,S2		
BLAZER S-15 Downsize	2-DR	1984-1991	55318	T-CONNECTOR	20	2W	N/A	S6		
ENVOY	w/Factory 7-way	2002-2008	55384	T-CONNECTOR	5	2W	N/A	S7	4,10	
	w/o Factory 7-way	1999-2001	55411	T-CONNECTOR	15	2W	N/A	S7		
JIMMY	Full Size	1985-1991	55312	T-CONNECTOR	5	2W	N/A	S1,S2		
JIMMY S10/S15 Downsize	ALL	1995-2001	55411	T-CONNECTOR	15	2W	N/A	S7		
G-SERIES VAN	ALL	1987-1995	55338	T-CONNECTOR	10	2W	N/A	S1,S2		
SAFARI	ALL	1995-2005	55411	T-CONNECTOR	15	2W	N/A	S4		
SAVANA	ALL	2003-2008	55540	T-CONNECTOR	20	2W	N/A	S3,S4		
		2000-2002	55377	T-CONNECTOR	10	3W	C1	S3,S4	9	
		1996-1999	55335	T-CONNECTOR	20	3W	C1	S3,S4	9	
	w/Factory 4-Flat	2003-2003	55240	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S4	11	
		1996-2002	55240	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S4	11	
YUKON	New Body w/Amber Turn Signals	2000-2008	55384	T-CONNECTOR	5	2W	N/A	S6	4,10	
	Old Body Style	1992-2000	55319	T-CONNECTOR	5	2W	N/A	S6		
YUKON DENALI	New Body w/Amber Turn Signals	2001-2008	55384	T-CONNECTOR	5	2W	N/A	S6	4,10	

Curt Manufacturing 2008 T-Connector Applications

YUKON XL	Old Body Style	1999-2000	55319	T-CONNECTOR	5	2W	N/A	S6	
YUKON XL DENALI	ALL	2000-2008	55384	T-CONNECTOR	5	2W	N/A	S6	4,10
YUKON XL DENALI	ALL	2001-2008	55384	T-CONNECTOR	5	2W	N/A	S6	4,10
GMC COMPACT PICKUP									
CANYON	w/Factory 7-way	2008-2008	55384	T-CONNECTOR	5	2W	N/A	T4	10
	w/o Factory 7-way	2004-2008	55510	T-CONNECTOR	10	3W	C1	T3	9
S-15 & SONOMA PICKUP	ALL	1998-2004	55359	T-CONNECTOR	5	2W	N/A	T3	
		1985-1997	55312	T-CONNECTOR	5	2W	N/A	T3	
	2-DR	1992-1994	55413	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S3	
GMC PICKUP FULL-SIZE									
C/K SERIES PICKUP	ALL, Except 88-91 Crew Cab	1988-2000	55315	T-CONNECTOR	5	2W	N/A	T3	
		1985-1987	55312	T-CONNECTOR	5	2W	N/A	T3	
		1973-1984	55311	T-CONNECTOR	5	2W	N/A	T3	
C/K SERIES PICKUP	Crew Cab, Old Body Style	1988-1991	55312	T-CONNECTOR	5	2W	N/A	T3	
SIERRA	Classic & New Body	1999-2008	55515	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	T3 OR T4	
	Classic & New Body w/Factory 7-way	2007-2008	55384	T-CONNECTOR	5	2W	N/A	T3	4,10
		2007-2007	56000	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T3	
	w/Factory 7-way	1999-2006	55384	T-CONNECTOR	5	2W	N/A	T3	4,10
		1999-2006	56000	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T3	
SYCLONE		1991-1992	55312		5	2W	N/A	T3	
HONDA									
ACCORD	2-DR	2008-2008	55502	T-CONNECTOR	10	3W	C1	P3	9
	4-DR	2003-2008	55502	T-CONNECTOR	10	3W	C1	P3	9
	ALL	1994-2002	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	P3	9
CIVIC	4-DR	2006-2008	56011	T-CONNECTOR	20	3W	C1	P3,P4	9
CRV	ALL	2007-2008	55106	T-CONNECTOR	30	3W	C1	S3	9
		1997-2006	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	S3	9
ELEMENT	ALL	2007-2008	56029	Replacement OEM Tow Package Wiring Harness (4-flat)	20	3W	C3	S8	
		2003-2004	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	S1,S2	9
FIT	ALL	2007-2008	56011	T-CONNECTOR	20	3W	C1	P3,P4	9
ODYSSEY	ALL	2005-2008	56007	T-CONNECTOR	15	3W	C3	S4	7
		1995-2004	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	S3	9
PASSPORT	ALL	1998-2002	55360	T-CONNECTOR	15	3W	C1	S1,S2	9
		1994-1997	55331	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C1	S1,S2	9
PILOT	ALL	2003-2008	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	S1,S2	9
PRELUDE	ALL	2001-2002	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	P3,P4	9
RIDGELINE	ALL	2006-2008	55585	T-CONNECTOR	10	3W	C1	P1,P2	9
HUMMER									
H2	w/Factory 7-way	2003-2008	55384	T-CONNECTOR	5	2W	N/A	S6	4,10
H3	w/Factory 7-way	2006-2008	55384	T-CONNECTOR	5	2W	N/A	S6	4,10
HYUNDAI									
AZERA	ALL	2006-2008	55400	T-CONNECTOR	20	3W	C1	P3,P4	2
ENTOURAGE	ALL	2007-2008	55503	T-CONNECTOR	25	3W	C1	S1,S2	9
SANTA FE	ALL	2007-2008	55538	T-CONNECTOR	20	3W	C1	S3,S4	
		2001-2006	55310	T-CONNECTOR	20	3W		S3,S4	9
TUCSON	ALL	2005-2008	55528	T-CONNECTOR	20	3W		S1,S2	9
VERACRUZ	ALL	2007-2007	56024	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W		S5	
INFINITI									
G35	ALL	2007-2007	N/A	T-CONNECTOR		3W	C3	P3,P4	
QX4	ALL	1997-2003	55361	T-CONNECTOR	20	3W	C1	S1,S2	9
QX56	w/Factory 7-way	2004-2008	55384	T-CONNECTOR	20	2W	N/A	S6	4,10
ISUZU									
AMIGO	ALL	1998-2000	55360	T-CONNECTOR	15	3W	C1	S1,S2	9
ASCENDER	w/Factory 7-way	2003-2007	55384	T-CONNECTOR	20	2W	N/A	S6	4,10
HOMBRE	ALL	1998-2000	55359	T-CONNECTOR	5	2W	N/A	T3	
		1996-1997	55312	T-CONNECTOR	5	2W	N/A	T3	
OASIS	ALL	1996-1999	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	S3	9
PICKUP I-SERIES	ALL	2006-2008	55510	T-CONNECTOR	10	3W	C1	T3	9
PICKUP	ALL	1989-1995	55305	T-CONNECTOR	10	3W	C1	T1,T2	9

Curt Manufacturing 2008 T-Connector Applications

RODEO	ALL	1998-2004	55360	T-CONNECTOR	15	3W	C1	S1,S2	9
		1992-1997	55331	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C1	S1,S2	9
RODEO SPORT	ALL	2000-2003	55360	T-CONNECTOR	15	3W	C1	S1,S2	9
TROOPER	ALL	1992-2002	55339	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C1	S5	9
JEEP									
CHEROKEE	ALL	1997-2001	55354	T-CONNECTOR	20	3W	C1	S3	9
		1991-1996	55330	T-CONNECTOR	20	3W	C1	S3	
		1976-1982	55495	T-CONNECTOR	10	2W	N/A	S5	
COMMANDER	ALL	2006-2008	55414	T-CONNECTOR	15	3W	C1	S1,S2	9
COMPASS	ALL	2007-2008	55050	T-CONNECTOR	30	3W	C3	S1,S2	7
GRAND CHEROKEE	ALL	2007-2008	56009	T-CONNECTOR	15	2W	N/A	S1,S2	
		2005-2006	55451	T-CONNECTOR	20	3W	C1	S1,S2	9
		1999-2004	55369	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C3	S3,S4	9
		1994-1998	55349	T-CONNECTOR	25	3W	C3	S3,S4	7
		1993-1993	55348	T-CONNECTOR	25	3W	C3	S3,S4	9
GRAND CHEROKEE	w/Factory 7-way	2005-2008	55381	T-CONNECTOR	5	2W	N/A	S5	4,10
		2000-2004	55381	T-CONNECTOR	5	2W	N/A	S1,S2	4,10
	w/Tow Package	1995-1998	55260	T-CONNECTOR	25	3W	C3	S3	7
GRAND WAGONEER	ALL	1993-1993	55348	T-CONNECTOR	25	3W	C3	S3,S4	9
LIBERTY	ALL	2008-2008	55027	T-CONNECTOR	15	3W	C1	S1,S2	9
		2002-2007	55382	T-CONNECTOR	10	3W	C1	S1,S2	9
PATRIOT	ALL	2008-2008	56019	T-CONNECTOR	30	2W	C3	S1,S2	
		2007-2007	55050	T-CONNECTOR	30	3W	C3	P1,P2	7
TJ (Canada)	ALL	2005-2006	55363	T-CONNECTOR	10	2W	N/A	S5,S7	
		1998-2004	55363	T-CONNECTOR	10	2W	N/A	S5,S7	
		1997-1997	55356	T-CONNECTOR	10	2W	N/A	S5,S7	
		1991-1995	55356	T-CONNECTOR	10	2W	N/A	S5,S7	
WAGONEER	ALL	1976-1982	55495	T-CONNECTOR	10	2W	N/A	S5	
WRANGLER	ALL	2007-2008	55124	T-CONNECTOR	10	2W	N/A	S1	
		2005-2006	55363	T-CONNECTOR	10	2W	N/A	S5,S7	
		1998-2004	55363	T-CONNECTOR	10	2W	N/A	S5,S7	
		1997-1997	55356	T-CONNECTOR	10	2W	N/A	S5,S7	
		1991-1995	55356	T-CONNECTOR	10	2W	N/A	S5,S7	
KIA									
RONDO	ALL	2007-2008	56023	T-CONNECTOR	30	3W	C2	S1,S2	
SEDONA	ALL	2006-2008	55503	T-CONNECTOR	25	3W	C1	S1,S2	9
		2002-2005	55309	T-CONNECTOR	25	3W	C1	S1,S2	9
SORENTO	ALL	2007-2008	56024	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C2	S5	
		2003-2006	55550	T-CONNECTOR	5	3W	C1	S7	9
SPORTAGE	ALL	2005-2008	55529	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C1	S5	9
		1998-2002	55371	T-CONNECTOR	20	3W	C1	S3,S4	9
LEXUS									
LX 450	ALL	1996-1997	55357	T-CONNECTOR	5	3W	C1	S6	9
LX 470	ALL	2001-2007	55245	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S6	11
		1998-1999	55365	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C1	S6	9
RX 300	ALL	2001-2003	55245	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S6	11
RX 330	ALL	2003-2006	55563	T-CONNECTOR	20	3W	C1	S3	9
LINCOLN									
AVIATOR	ALL	2003-2004	55344	T-CONNECTOR	10	2W	N/A	S1,S2	
	w/Tow Package	2003-2005	55251	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S7	11
LS	ALL	2000-2006	55373	T-CONNECTOR	20	3W	CL	P3,P4	7,8
MKX	ALL	2007-2008	56014	T-CONNECTOR	10	2W	N/A	S1,S2	
NAVIGATOR	ALL	1998-2003	55344	T-CONNECTOR	10	2W	N/A	S1,S2	
	w/Factory 4-flat	2000-2002	55250	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S5	11
		1997-1999	55249	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S5	11
MAZDA									
3	ALL	2004-2008	56011	T-CONNECTOR	20	3W	C1	P3,P4	
5	ALL	2006-2007	56016	T-CONNECTOR	30	3W	C3	S3,S4	
6	4-DR Sedan	2003-2008	55567	T-CONNECTOR	25	3W	C3	P3,P4	7
	5-DR Hatchback	2004-2008	55567	T-CONNECTOR	25	3W	C3	P3,P4	7

Curt Manufacturing 2008 T-Connector Applications

B-SERIES PICKUP	ALL	1994-2007	55325	T-CONNECTOR	5	3W	C1	T1,T2	9
		1985-1993	55304	T-CONNECTOR	5	3W	C1	T1,T2	9
	w/Factory 4-flat	1998-2001	55241	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	T3	11
CX-7	ALL	2007-2008	55593	T-CONNECTOR	25	3W	C3	S4	9
CX-9	ALL	2007-2007	56016	T-CONNECTOR	30	3W	C3	S3,S4	
MPV	ALL	2000-2006	56010	T-CONNECTOR	20	3W	C1	S3,S4	9
NAVAJO	ALL	1991-1994	55324	T-CONNECTOR	20	2W	N/A	S1	
TRIBUTE	ALL	2008-2008	56014	T-CONNECTOR	10	2W	N/A	S1,S2	
		2005-2006	55568	T-CONNECTOR	10	3W	C1	S1,S2	9
		2001-2003	55343	T-CONNECTOR	10	3W	C1	S1,S2	9
TRIBUTE	w/Tow Package	2001-2004	55255	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S3	11
MERCURY									
GRAND MARQUIS	ALL	1992-1997	55326	T-CONNECTOR	20	2W	N/A	P3,P4	
MARINER	ALL	2005-2008	56014	T-CONNECTOR	10	2W	N/A	S1,S2	
MONTEREY	ALL	2004-2007	55545	T-CONNECTOR	25	2W	N/A	S1,S2	7
		2004-2007	55545-RK	T-CONNECTOR	5	N/A	N/A	N/A	
MOUNTAINEER	ALL	2002-2003	55344	T-CONNECTOR	10	2W	N/A	S1,S2	
		1997-2001	55345	T-CONNECTOR	25	3W	C3	S1,S2	7
	w/Factory 4-flat	2002-2005	55251	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S7	11
SABLE	ALL	1997-2001	55241	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S5	11
		2008-2008	56015	T-CONNECTOR	20	2W	N/A	P3,P4	
		2000-2003	55375	T-CONNECTOR	10	2W	N/A	P3,P4	
		1996-1999	55333	T-CONNECTOR	10	3W	C1	P3,P4	9
		1992-1995	55351	T-CONNECTOR	10	2W	N/A	P3,P4	
TRACER	4-DR	1997-1999	55344	T-CONNECTOR	10	2W	N/A	P1,P2	
VILLAGER	ALL	1998-1998	55362	T-CONNECTOR	20	3W	C1	S1,S2	9
MITSUBISHI									
MONTERO	ALL	2001-2007	55380	T-CONNECTOR	20	3W	C1	S1,S2	9
		1992-2000	55464	T-CONNECTOR	20	3W	C1	S1,S2	
MONTERO SPORT	ALL	1997-2001	55477	T-CONNECTOR	20	3W	C1	S1,S2	
OUTLANDER	ALL	2003-2006	55565	T-CONNECTOR	25	3W	C1	S3,S4	9
RAIDER	ALL	2006-2007	55323	T-CONNECTOR	10	2W	N/A	T1,T2	
NISSAN									
ALTIMA	ALL	2007-2008	56022	T-CONNECTOR	30	3W	C2	P3,P4	
		1998-2001	55361	T-CONNECTOR	20	3W	C1	P3,P4	9
FRONTIER	w/Factory Tow Package	2005-2008	55441	Replacement OEM Tow Package Wiring Harness (4-flat)	5	2W	N/A	T3	
	ALL	1998-2003	55362	T-CONNECTOR	5	3W	C1	T5	9
MAXIMA	ALL	2004-2008	56022	T-CONNECTOR	30	3W	C2	P3,P4	
MURANO	ALL	2003-2005	55571	T-CONNECTOR	25	3W	C3	S3,S4	7
PATHFINDER	w/Factory Tow Package	2005-2008	55441	Replacement OEM Tow Package Wiring Harness (4-flat)	5	2W	N/A	S5	
	ALL	1996-2004	55361	T-CONNECTOR	20	3W	C1	S1,S2	9
		1987-1995	55353	T-CONNECTOR	10	3W	C1	S1,S2	9
PATHFINDER ARMADA	w/Factory 7-way	2004-2007	55384	T-CONNECTOR	5	2W	N/A	S6	4,10
PICKUP	ALL	1986.5-1997	55353	T-CONNECTOR	10	3W	C1	T1,T2	9
QUEST	ALL	2003-2007	55570	T-CONNECTOR	10	3W	C1	S1,S2	7
		1998-1998	55362	T-CONNECTOR	20	3W	C1	S1,S2	9
ROGUE	ALL	2008-2008	56033	Replacement OEM Tow Package Wiring Harness (4-flat)	30	3W	C3	S3,S4	
SENTRA	ALL	2007-2008	56022	T-CONNECTOR	30	3W	C2	P3,P4	
TITAN	w/Factory 7-way	2004-2008	55384	T-CONNECTOR	5	2W	N/A	T3	4,10
		2004-2008	56000	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T3	
VERSA	ALL	2007-2008	56021	T-CONNECTOR	30	3W	C2	P3,P4	
XTERRA	w/Factory Tow Package	2005-2008	55441	Replacement OEM Tow Package Wiring Harness (4-flat)	5	2W	N/A	S5	
		2000-2004	55244	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S7	11
OLDSMOBILE									
BRAVADA	w/Factory 7-way	2002-2004	55384	T-CONNECTOR	15	2W	N/A	S6	4,10
	ALL	1995-2001	55411	T-CONNECTOR	15	2W	N/A	S7	
CUSTOM CRUISER WAGON	ALL	1991-1992	55352	T-CONNECTOR	10	2W	N/A	P3,P4	
SILHOUETTE	ALL	1997-2004	55355	T-CONNECTOR	10	3W	C1	S3	9
		1993-1996	55337	T-CONNECTOR	20	2W	N/A	S1,S2	9
PLYMOUTH									

Curt Manufacturing 2008 T-Connector Applications

GRAND VOYAGER	ALL	1996-2000	55334	T-CONNECTOR	20	3W	C1	S1,S2	9
		1991-1995	55323	T-CONNECTOR	10	2W	N/A	S1,S2	
TRAILDUSTER	ALL	1986-1993	55317	T-CONNECTOR	5	2W	N/A	S5,S7	
VOYAGER	ALL	1996-2000	55334	T-CONNECTOR	20	3W	C1	S1,S2	9
		1991-1995	55323	T-CONNECTOR	10	2W	N/A	S1,S2	
		1989-1990	55493	T-CONNECTOR	10	?	?	S1,S2	
PONTIAC									
AZTEK	ALL	2001-2005	55383	T-CONNECTOR	20	2W	N/A	S1,S2	
G5	2-DR	2007-2008	55432	T-CONNECTOR	10	2W	NA	P1,P2	
	4-DR	2007-2008	55434	T-CONNECTOR	10	2W	NA	P1,P2	
	GT (2-DR)	2007-2008	55432	T-CONNECTOR	10	2W	NA	P1,P2	
G5 PURSUIT Canada Only	2-DR	2005-2008	55432	T-CONNECTOR	10	2W	NA	P1,P2	
	4-DR	2005-2008	55434	T-CONNECTOR	10	2W	NA	P1,P2	
	GT (2-DR)	2005-2008	55432	T-CONNECTOR	10	2W	NA	P1,P2	
G6	ALL	2007-2007	N/A	T-CONNECTOR	N/A	2W	N/A	P1,P2	
MONTANA SV6	ALL	2005-2006	55536	T-CONNECTOR	15	2W	N/A	S1,S2	
MONTANA	ALL	1999-2005	55355	T-CONNECTOR	10	3W	C1	S3	9
TORRENT	ALL	2007-2008	56012	Replacement OEM Tow Package Wiring Harness (4-flat)	15	2W	N/A	S3	
		2006-2006	55560	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C3	S3	9
TRANS SPORT VAN	ALL Including Montana	1997-1998	55355	T-CONNECTOR	10	3W	C1	S3	9
		1993-1996	55337	T-CONNECTOR	20	2W	N/A	S1,S2	9
VIBE	ALL	2003-2008	55057	T-CONNECTOR	25	3W	C3	?	7
SAAB									
9-7X	w/Factory 7-way	2005-2007	55384	T-CONNECTOR	5	2W	N/A	S6	4,10
SATURN									
AURA	ALL	2007-2008	56017	T-CONNECTOR	20	3W	C1	P1,P2	
OUTLOOK	ALL	2007-2008	56025	T-CONNECTOR	15	2W	N/A	S1,S2	
	w/Factory 7-way	2007-2008	55384	T-CONNECTOR	5	2W	N/A	S5	4,10
RELAY	ALL	2005-2007	55536	T-CONNECTOR	15	2W	N/A	S1,S2	
VUE	ALL	2008-2008	56026	T-CONNECTOR	30	3W	C3	S3,S4	
		2002-2007	56018	T-CONNECTOR	15	3W	C1	S1,S2	
SCION									
XB	ALL	2004-2007	56030	T-CONNECTOR	20	3W	C1	S1,S2	
SUBARU									
B9 TRIBECA	ALL	2006-2008	55370	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C3	S8	7
FORESTER	ALL	1998-2008	55370	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C3	S4	7
LEGACY WAGON	Outback Only	1996-1999	55370	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C3	P3,P4	7
OUTBACK WAGON	ALL Except Sport	2000-2008	55370	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C3	P3,P4	7
SUZUKI									
GRAND VITARA	ALL	2006-2008	56002	T-CONNECTOR	20	3W	C1	S3,S4	9
		1999-2005	55372	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C1	S3	9
SX4	ALL	2007-2007	56002	T-CONNECTOR	20	3W	C1	S3,S4	9
VITARA	ALL	1999-2005	55372	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C1	S3	9
XL-7	ALL	2007-2008	56012	Replacement OEM Tow Package Wiring Harness (4-flat)	15	2W	N/A	S4	
		2001-2006	55372	T-CONNECTOR	5	3W	C1	S3	9
TOYOTA									
4RUNNER	ALL	1996-2002	55341	T-CONNECTOR	20	3W	C1	S3,S4	
		2001-2002	55245	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S3,S4	11
CAMRY	4-DR Except Hybrid	2007-2009	55567	T-CONNECTOR	25	3W	C3	P3,P4	7
	4-DR	2002-2006	55308	T-CONNECTOR	5	3W	C1	P3,P4	9
		1997-2001	55358	T-CONNECTOR	5	3W	C1	P3,P4	9
COROLLA	ALL	2003-2009	55542	T-CONNECTOR	15	3W	C1	P3,P4	9
ECHO	ALL	2000-2002	55522	T-CONNECTOR	20	3W	C1	P3,P4	9
FJ CRUISER	ALL	2007-2007	55567	T-CONNECTOR	25	3W	C3	S3,S4	7
HIGHLANDER	ALL	2008-2008	56034	Replacement OEM Tow Package Wiring Harness (4-flat)	30	3W	C3	S3,S4	
	ALL Except Hybrid	2001-2007	55400	T-CONNECTOR	20	3W	C1	S3,S4	2
	ALL	2001-2003	55245	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S6	11
LANDCRUISER	ALL	2001-2002	55245	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S6	11
		1998-1999	55365	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C1	S6	9

Curt Manufacturing 2008 T-Connector Applications

MATRIX	ALL	1996-1997	55357	T-CONNECTOR	5	3W	C3	S6	9
PICKUP	ALL Except T-100	2003-2007	55522	T-CONNECTOR	20	3W	C1	S3,S4	9
RAV4	ALL	1989-1995	55379	T-CONNECTOR	10	3W	C1	T1,T2	9
		2006-2008	55113	T-CONNECTOR	25	3W	C3	S3,S4	
		2001-2005	55307	T-CONNECTOR	20	3W	C1	S3,S4	9
		1996-2000	55486	T-CONNECTOR	20	3W	C1	S3,S4	9
SCION XB	ALL	2004-2007	56030	T-CONNECTOR	20	3W	C1	S1,S2	
SEQUOIA	ALL	2001-2002	55246	Replacement OEM Tow Package Wiring Harness (4-flat)	5	2W	N/A	S7	11
SIENNA	ALL	2004-2008	55580	T-CONNECTOR	10	3W	C1	S1,S2	9
		1998-2003	55418	T-CONNECTOR	10	3W	C1	S3,S4	9
T-100	ALL	1993-1998	55513	T-CONNECTOR	10	3W	C1	T3,T5	9
TACOMA	ALL	2005-2006	55513	T-CONNECTOR	10	3W	C1	T1,T2	9
		1995.5-2004	55379	T-CONNECTOR	10	3W	C1	T1,T2	9
TUNDRA	ALL	2001-2002	55378	T-CONNECTOR	10	3W	C5	T3	7
		2000-2000	55367	T-CONNECTOR	10	3W	C3	T3	7
CONVERTER TYPE CODES		OLD WIRING CODES							
C1 - Converter		1 = Standard 2-wire system							
C2 - Converter, Circuit Protected		2 = 3-wire system, requires converter							
C3 - Converter, Powered		3 = May be 2 or 3-wire system							
C4 - Converter Circuit Protected & Powered		4 = Adds 4-way to OEM 7-way							
C5 - Converter, Circuit Protected & Powered w/ Relay		5 = Powered converter required							
CL - Converter, Low-Side Switching		6 = Powered converter recommended							
		7 = Powered converter included							
ELECTRICAL SYSTEM CODES		8 = Low-side switching system							
2W - Standard 2-wire system		9 = Circuit protected converter included							
3W - 3-wire system		10 = W/OEM Tow Package							
MP - Multiplex system		11 = OEM replacement end or socket							
WIRE LOCATION CODES		12 = Upgrade OEM to 7-way w/ relays							
SEE DIAGRAM ON PAGE 80 OF THE 2008 CURT CATALOG OR AT WWW.CURTMFG.COM		13 = N/A, see your new car dealer							
		14 = Upgrade OEM to 6-way w/ relays							
		15 = OEM plug to 7RV & 4-flat							
		16 = OEM plug to 6-round & 4 flat							