

Indicates change from last listing 3.6.09	MAKE/MODEL	TYPE	YEARS	PART #	TYPE	INSTALL TIME	ELEC. SYSTEM	MINIMUM CONVERTER TYPE	WIRE LOCATION	OLD CODE
	ACURA									
	CL SERIES	All	1997-2003	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	P3	
	INTEGRA	All	1994-2001	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	P3	
	MDX	All	2007-2008	56038	Replacement OEM Tow Package Wiring Harness (4-flat)	15	3W	C3	S3	
			2001-2006	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	S3	
	RDX	All	2007-2007	56008	T-Connector	25	3W	C3	P3	
	RL SERIES	All	1996-2001	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	P3	
	SLX	All	1996-1999	55339	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C1	S5	
	TL SERIES	All	1996-2003	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	P3	
	TSX	Full Size All	2006-2009	55502	T-Connector	10	3W	C1	P3	
BUICK										
	ENCLAVE	All	2008-2009	56027	T-Connector	10	2W	N/A	P1,P2	
		w/Factory 7-way	2008-2009	55384	T-Connector	10	2W	N/A	S5	4,10
	RAINIER	w/Factory 7-way	2004-2008	55384	T-Connector	10	2W	N/A	S6	4,10
	RENDEZVOUS	All	2002-2007	55383	T-Connector	20	2W	N/A	S1,S2	
	ROADMASTER	All	1991-1996	55347	T-Connector	10	2W	N/A	P3,P4	
	ROADMASTER ESTATE WAGON	All	1991-1996	55352	T-Connector	10	2W	N/A	P3,P4	
	TERRAZA	All	2005-2007	55536	T-Connector	15	2W	N/A	S1,S2	
CADILLAC										
	ESCALADE	w/Factory 7-way	2002-2008	55384	T-Connector	5	2W	N/A	S6	4,10
		Old Body Style	1999-2000	55319	T-Connector	5	2W	N/A	S7	
	ESCALADE ESV	w/Factory 7-way	2003-2008	55384	T-Connector	5	2W	N/A	S6	4,10
	ESCALADE EXT	w/Factory 7-way	2002-2008	55384	T-Connector	5	2W	N/A	S6	4,10
	CTS	All	2008-2009	56044	T-Connector	20	2w	C3	P1,P2	
			2003-2007	56043	T-Connector	45	3W	C3	P3,P4	
	CTS-V	All	2004-2007	56043	T-Connector	45	3W	C3	P3,P4	
CHEVROLET PASSENGER & WAGON										
	CAPRICE	All	1991-1996	55347	T-Connector	10	2W	N/A	P3,P4	
	CAPRICE ESTATE WAGON	All	1991-1996	55352	T-Connector	10	2W	N/A	P3,P4	
	COBALT	2-Door	2005-2009	55432	T-Connector	15	2W	N/A	P1,P2	
		4-Door	2005-2009	55434	T-Connector	10	2W	N/A	P1,P2	
		SS 2-Door	2005-2009	55432	T-Connector	15	2W	N/A	P1,P2	
		SS 4-Door	2005-2009	55434	T-Connector	10	2W	N/A	P1,P2	
	IMPALA SS	All	1994-1996	55347	T-Connector	10	2W	N/A	P3,P4	
	MALIBU	All Except LTZ	2008-2009	56027	T-Connector	10	2W	N/A	P1,P2	
		All	2004-2007	56013	T-Connector	20	2W	N/A	P1,P2	
CHEVROLET VAN & SPORT UTILITY VEHICLE										
	ASTRO	All	1995-2005	55411	T-Connector	15	2W	N/A	S4	
	AVALANCHE	w/Factory 7-way	2002-2009	55384	T-Connector	5	2W	N/A	S6	4,10
	BLAZER	Full Size All	1992-1994	55319	T-Connector	5	2W	N/A	S6	
			1985-1991	55312	T-Connector	5	2W	N/A	S1,S2	
			1973-1984	55311	T-Connector	5	2W	N/A	S1,S2	
	BLAZER S-10 Downsize	2-Door	1984-1991	55318	T-Connector	20	2W	N/A	S6	
	BLAZER S10/S15		1995-2002	55411	T-Connector	15	2W	N/A	S7	
	EQUINOX	All	2007-2008	56012	Replacement OEM Tow Package Wiring Harness (4-flat)	15	2W	N/A	S3	
			2005-2006	55560	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C3	S3	9
	EXPRESS	All	2003-2009	55540	T-Connector	20	2W	N/A	S3,S4	
			2000-2002	55377	T-Connector	10	3W	C1	S3,S4	9
			1996-1999	55335	T-Connector	20	3W	C1	S3,S4	9
		w/Factory 4-flat	2003-2003	55240	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S4	11

G-SERIES VAN	All	1996-2002	55240	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S4	11
HHR	All	1987-1995	55338	T-Connector	10	2W	N/A	S1,S2	
LUMINA APV VAN	All	2006-2009	55432	T-Connector	15	2W	N/A	S3,S4	
SUBURBAN	All	1993-1996	55337	T-Connector	20	2W	N/A	S1,S2	9
	New Body w/Amber Turn Signals	2000-2009	55384	T-Connector	5	2W	N/A	S6	4,10
	Old Body Style	1992-1999	55319	T-Connector	5	2W	N/A	S6	
	All	1985-1991	55312	T-Connector	5	2W	N/A	S5	
		1973-1984	55311	T-Connector	5	2W	N/A	S5	
TAHOE	New Body w/Amber Turn Signals	2000-2009	55384	T-Connector	5	2W	N/A	S6	4,10
	Old Body Style	1995-2000	55319	T-Connector	5	2W	N/A	S6	
TRACKER	All	1999-2004	55372	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C1	S1,S2	9
TRAILBLAZER	w/Factory 7-way	2002-2009	55384	T-Connector	5	2W	N/A	S6	4,10
TRAVERSE	All	2009-2009	56027	T-Connector	10	2W	N/A	S6	
	w/Factory 7-way	2009-2009	55384	T-Connector	5	2W	N/A	S6	4,10
UPLANDER	All	2005-2008	55536	T-Connector	15	2W	N/A	S1,S2	
VENTURE	All	1997-2005	55355	T-Connector	10	3W	C1	S3	9
CHEVROLET COMPACT TRUCK									
COLORADO	All w/o Factory 7-way	2004-2009	55510	T-Connector	10	3W	C1	T3	9
	w/Factory 7-way	2008-2008	55384	T-Connector	5	2W	N/A	T4	10
S-10 PICKUP	All	1998-2004	55359	T-Connector	5	2W	N/A	T3	
		1985-1997	55312	T-Connector	5	2W	N/A	T3	
	2-Door	1992-1994	55413	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S3	
CHEVROLET PICKUP FULL-SIZE									
C/K SERIES PICKUP	All Except 88-91 Crew Cab	1988-2000	55315	T-Connector	5	2W	N/A	T3	
	All	1985-1987	55312	T-Connector	5	2W	N/A	T3	
		1973-1984	55311	T-Connector	5	2W	N/A	T3	
C/K SERIES PICKUP	Crew Cab, Old Body Style	1988-1991	55312	T-Connector	5	2W	N/A	T3	
SILVERADO	Classic & New Body	1999-2008	55515	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	T3 OR T4	
	Classic & New Body w/Factory 7-way	2007-2009	55384	T-Connector	5	2W	N/A	T3	4,10
		2007-2007	56000	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T3	
	w/Factory 7-way	1999-2006	55384	T-Connector	5	2W	N/A	T3	4,10
		1999-2006	56000	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T3	
CHRYSLER									
300	All	2005-2007	55534	T-Connector	10	2W	N/A	P3,P4	
300C	All	2005-2009	55546	T-Connector	15	3W	C3	P3,P4	9
300M	All	1999-2004	55364	T-Connector	15	3W	C1	P1,P2	9
ASPEN	All	2007-2009	55597	T-Connector	25	3W	C3	S1,S2	9
		2007-2008	55381	T-Connector	5	2W	N/A	S6	10
CONCORDE	All	1998-2002	55364	T-Connector	15	3W	C1	P1,P2	9
INTREPID	Canada Only	1998-2004	55364	T-Connector	15	3W	C1	P1,P2	9
LHS	All	1999-1999	55364	T-Connector	15	3W	C1	P1,P2	9
PACIFICA	All	2004-2008	55530	T-Connector	25	3W	C3	S1,S2	7
PT CRUISER	All	2000-2009	55532	T-Connector	20	3W	C3	P1,P2	7
TOWN & COUNTRY	All	2008-2009	56019	T-Connector	N/A	2W	C3	S1,S2	
		2004-2007	55537	T-Connector	20	2W	N/A	S1,S2	
		2001-2003	55376	T-Connector	15	3W	C1	S1,S2	9
		1996-2000	55334	T-Connector	20	3W	C1	S1,S2	9
		1991-1995	55323	T-Connector	10	2W	N/A	S1,S2	
		1989-1990	55493	T-Connector	10	2W	?	S1,S2	
VOYAGER	All	2001-2003	55376	T-Connector	15	3W	C1	S1,S2	9
DODGE PASSENGER & WAGON									
AVENGER	All	2008-2009	56028	T-Connector	30	3W	C3	P1,P2	
CALIBER	All	2008-2009	56019	T-Connector	30	2W	C3	S1,S2	
		2007-2007	55050	T-Connector	30	3W	C3	P1,P2	7
CHALLENGER	All	2008-2009	55534	T-Connector	15	2W	N/A	P3,P4	
CHARGER	All	2006-2009	55534	T-Connector	10	2W	N/A	P3,P4	

INTREPID	All	1998-2004	55364	T-Connector	15	3W	C1	P1,P2	9
MAGNUM	All	2005-2008	55562	T-Connector	30	3W	C3	P1,P2	7
DODGE VAN & SPORT UTILITY VEHICLE									
CARAVAN	All	2004-2007	55537	T-Connector	20	2W	N/A	S1,S2	
		2001-2003	55376	T-Connector	15	3W	C1	S1,S2	9
		1996-2000	55334	T-Connector	20	3W	C1	S1,S2	9
		1991-1995	55323	T-Connector	10	2W	N/A	S1,S2	
		1989-1990	55493	T-Connector	10	2W	?	S1,S2	
DURANGO	All	2004-2009	55597	T-Connector	25	3W	C3	S1,S2	9
		1998-2003	55334	T-Connector	20	3W	C1	S1,S2	9
GRAND CARAVAN	w/Factory 7-way	2000-2007	55381	T-Connector	5	2W	N/A	S1,S2	4,10
	All	2008-2009	56019	T-Connector	30	2W	C3	S1,S2	
JOURNEY	All	2004-2007	55537	T-Connector	20	2W	N/A	S1,S2	
		2001-2003	55376	T-Connector	15	3W	C1	S1,S2	9
		1996-2000	55334	T-Connector	20	3W	C1	S1,S2	9
		1991-1995	55323	T-Connector	10	2W	N/A	S1,S2	
		2009-2009	56037	T-Connector	30	3W	C3	S1,S2	
NITRO	All	2007-2009	55027	T-Connector	15	3W	C1	S1,S2	9
SPRINTER	w/Factory 7-way	2003-2007	55381	T-Connector	5	2W	N/A	S3,S4	4,10
VAN, FULL SIZE	w/Factory 7-way	2001-2003	55381	T-Connector	5	2W	N/A	S5	4,10
VAN, B-SERIES, FULL SIZE	All	1999-2000	55368	Replacement OEM Tow Package Wiring Harness (4-flat)	5	2W	N/A	S5	
	All	1993-1998	55328	T-Connector	5	2W	N/A	S7	
DODGE COMPACT PICKUP									
DAKOTA	All	2003-2008	55323	T-Connector	10	2W	N/A	T1,T2	
		1995-2003	55329	T-Connector	5	2W	N/A	T3,T5	6
		1987-1994	55317	T-Connector	5	2W	N/A	T3,T5	
	w/Factory 7-way	2000-2008	55381	T-Connector	5	2W	N/A	T3,T5	4,10
			1995-2008	56001	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T3,T5
DODGE PICKUP FULL-SIZE									
RAM 1500	w/Factory 7-way	2009-2009	55384	T-Connector	5	2W	N/A	T3	10
	All	2002-2005	55504	T-Connector	10	3W	C1	T3,T5	9
		1995-2001	55329	T-Connector	5	2W	N/A	T3,T5	6
RAM 2500/3500	w/Factory 7-way	1995-2008	56001	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T3,T5	
	All	2003-2005	55504	T-Connector	10	3W	C1	T3,T5	9
		2002-2002	55329	T-Connector	5	2W	N/A	T3,T5	6
RAM PICKUP, FULL SIZE	w/Factory 7-way	1995-2008	56001	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T3,T5	
	w/Factory 7-way	2000-2009	55381	T-Connector	5	2W	N/A	T3,T5	4,10
	All	1994-1994	55317	T-Connector	5	2W	N/A	T1,T2	
RAMCHARGER	All	1986-1993	55317	T-Connector	5	2W	N/A	T1,T2	
		1986-1993	55317	T-Connector	5	2W	N/A	S5,S7	
FORD PASSENGER & WAGON									
EDGE	All	2007-2008	56014	T-Connector	10	2W	N/A	S1,S2	
ESCORT	4-Door	1997-1999	55344	T-Connector	10	2W	N/A	P1,P2	
ESCORT ZX2	All	1998-2003	55344	T-Connector	10	2W	N/A	P1,P2	
		1973-1979	55301	T-Connector	5	2W	N/A	T3	
FIVE HUNDRED	All	2005-2007	55587	T-Connector	10	2W	N/A	P3,P4	
FOCUS	All	2008-2008	56014	T-Connector	10	2W	N/A	P1,P2	
FOCUS WAGON	Built before 11/02	2000-2003	55344	T-Connector	10	2W	N/A	P1,P2	
LTD CROWN VICTORIA	All	1992-1997	55326	T-Connector	20	2W	N/A	P3,P4	
MUSTANG	All Except Cobra SVT 99-04	1994-2004	55326	T-Connector	20	2W	N/A	P3,P4	
TAURUS	All	2008-2009	56015	T-Connector	20	2W	N/A	P3,P4	
		2000-2003	55375	T-Connector	10	2W	N/A	P3,P4	
	All Including SHO	1996-1999	55333	T-Connector	10	3W	C1	P3,P4	9
			1992-1995	55327	T-Connector	10	2W	N/A	P3,P4
FORD VAN & SPORT UTILITY VEHICLE									
BRONCO	Full Size	1992-1996	55350	T-Connector	5	2W	N/A	S6	

2009 Curt Manufacturing T-Connector Application Guide

ECONOLINE	All	1989-1991	55303	T-Connector	5	2W	N/A	S5,S7		
		1987-1988	55302	T-Connector	5	2W	N/A	S5		
		1980-1986	55313	T-Connector	5	2W	N/A	S6		
		2004-2008	56020	T-Connector	15	2W	N/A	S1,S2		
		1995-2003	55344	T-Connector	10	2W	N/A	S1,S2		
ESCAPE	All Including Hybrid	1992-1994	55343	T-Connector	10	3W	C1	S1,S2	9	
		2008-2009	56014	T-Connector	10	2W	N/A	S1,S2		
		2005-2007	55568	T-Connector	10	3W	C1	S1,S2	9	
		2000-2003	55343	T-Connector	10	3W	C1	S1,S2	9	
		w/Tow Package	2001-2004	55255	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S3	11
EXCURSION	All	2000-2003	55344	T-Connector	10	2W	N/A	S1,S2		
		1997-2003	55344	T-Connector	10	2W	N/A	S1,S2		
EXPEDITION	w/Factory 4-flat	2000-2002	55250	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S5	11	
		1997-1999	55249	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S5	11	
EXPLORER	w/Tow Package	2002-2005	55251	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S7	11	
EXPLORER	w/Factory 4-flat	1995-2001	55241	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S5	11	
EXPLORER	2-Door Sport	2001-2003	55344	T-Connector	10	2W	N/A	S1,S2		
EXPLORER	4-Door	2002-2003	55344	T-Connector	10	2W	N/A	S1,S2		
EXPLORER	All	2001-2001	55345	T-Connector	25	3W	C3	S1,S2	7	
		1995-2000	55345	T-Connector	25	3W	C3	S1,S2	7	
		1991-1994	55324	T-Connector	20	2W	N/A	S1		
FREESTAR	All	2004-2007	56073	Replacement OEM Tow Package Wiring Harness (4-flat)	5	2W	N/A	S6		
		2004-2007	55545-RK	T-Connector		N/A	N/A	N/A		
FREESTYLE	All	2005-2007	55587	T-Connector	10	2W	N/A	S1,S2		
WINDSTAR	Built after 11/02	2003-2003	55525	T-Connector	25	3W	CL	S1,S2	7,8	
		1999-2003	55366	T-Connector	25	3W	CL	S1,S2	7,8	
		All	1995-1998	55346	T-Connector	20	3W	C1	S1,S2	9
FORD COMPACT PICKUP										
RANGER	All	2000-2003	55344	T-Connector	10	2W	N/A	T1,T2		
		1993-1999	55325	T-Connector	5	3W	C1	T3	9	
		1986-1992	55314	T-Connector	5	2W	N/A	T1,T2		
		w/Factory 4-flat	1998-1999	55241	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	T3	11
FORD PICKUP FULL-SIZE										
F-150 (New Body)	All	2005-2007	56031	Replacement OEM Tow Package Wiring Harness (4-flat)	10	2W	N/A	T3		
		2004-2004	55551	T-Connector	10	2W	N/A	T3	4,10	
		Mfg. 1/96-2004	1997-2004	55256	T-Connector	5	2W	N/A	T3	10
		w/Factory 4-flat (Mfg. 1/96-10/96)	1997-1997	55249	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	T3	11
		New Body Style w/Factory 7-way	2004-2008	56000	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T3	
F-150 HERITAGE	Old Body Style w/Factory 4-flat	2004-2004	55028	Upgrade Kit (Adds 6-way to 4-flat)	5	N/A	N/A	T3	14	
		2004-2004	55242	Replacement OEM Tow Package Wiring Harness (7-way)	5	N/A	N/A	T1,T2	14	
		Old Body Style w/Factory 7-way	2004-2004	56000	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T1,T2	
F-150 FLARESIDE	Flareside Only	1997-2003	55344	T-Connector	10	2W	N/A	T1,T2		
F-150 HERITAGE FLARESIDE	Heritage Flareside Only	2004-2004	55344	T-Connector	10	2W	N/A	T1,T2		
F-150 SUPERCREW	All	2000-2003	55344	T-Connector	10	2W	N/A	T1,T2		
F-250 LIGHT DUTY	w/Factory 4-flat	1997-2003	55028	Upgrade Kit (Adds 6-way to 4-flat)	5	N/A	N/A	T3	14	
		1997-2003	55242	Replacement OEM Tow Package Wiring Harness (7-way)	5	N/A	N/A	T3	14	
		All	1997-2001	55256	T-Connector	5	2W	N/A	T3	10
		w/Factory 4-flat	1997-1997	55249	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	T3	11
F-250 & F-350 SUPER DUTY	w/Factory 7-way	1997-2003	56000	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T1,T2		
		All	2005-2007	56032	T-Connector	10	2W	N/A	T3	
		w/Factory 4-flat	2002-2004	55265	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	T4	11
		1999-2001	55247	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	T3	11	
		1999-2001	55243	Replacement OEM Tow Package Wiring Harness (7-way)	5	N/A	N/A	T1,T2	14	
		1999-2001	55029	Upgrade Kit (Adds 6-way to 4-flat)	5	N/A	N/A	T3	14	
F-450 & F-550 SUPER DUTY	w/Factory 4-flat	1997-1997	55316	T-Connector	5	2W	N/A	T3		
		w/Factory 7-way	1999-2008	56000	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T1,T2	
		1999-2001	55029	Upgrade Kit (Adds 6-way to 4-flat)	5	N/A	N/A	T3	14	

2009 Curt Manufacturing T-Connector Application Guide

		1999-2001	55243	Replacement OEM Tow Package Wiring Harness (7-way)	5	N/A	N/A	T1,T2	14
	w/Factory 7-way	1999-2008	56000	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T1,T2	
F-100, F-150, F-250, F-350	All	1987-1996	55316	T-Connector	5	2W	N/A	T3	
F-SERIES	All	1980-1986	55313	T-Connector	5	2W	N/A	T3	
GMC VAN & SPORT UTILITY VEHICLE									
ACADIA	w/Factory 7-way	2007-2009	55384	T-Connector	5	2W	N/A	S5	4,10
BLAZER	Full Size	1973-1984	55311	T-Connector	5	2W	N/A	S1,S2	
BLAZER S-15 Downsize	2-Door	1984-1991	55318	T-Connector	20	2W	N/A	S6	
ENVOY	w/Factory 7-way	2002-2009	55384	T-Connector	5	2W	N/A	S7	4,10
	w/o Factory 7-way	1999-2001	55411	T-Connector	15	2W	N/A	S7	
JIMMY	Full Size	1985-1991	55312	T-Connector	5	2W	N/A	S1,S2	
JIMMY S10/S15 Downsize	All	1995-2001	55411	T-Connector	15	2W	N/A	S7	
G-SERIES VAN	All	1987-1995	55338	T-Connector	10	2W	N/A	S1,S2	
SAFARI	All	1995-2005	55411	T-Connector	15	2W	N/A	S4	
SAVANA	All	2003-2009	55540	T-Connector	20	2W	N/A	S3,S4	
		2000-2002	55377	T-Connector	10	3W	C1	S3,S4	9
		1996-1999	55335	T-Connector	20	3W	C1	S3,S4	9
	w/Factory 4-Flat	2003-2003	55240	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S4	11
		1996-2002	55240	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S4	11
YUKON	New Body w/Amber Turn Signals	2000-2009	55384	T-Connector	5	2W	N/A	S6	4,10
	Old Body Style	1992-2000	55319	T-Connector	5	2W	N/A	S6	
YUKON DENALI	New Body w/Amber Turn Signals	2001-2009	55384	T-Connector	5	2W	N/A	S6	4,10
	Old Body Style	1999-2000	55319	T-Connector	5	2W	N/A	S6	
YUKON XL	All	2000-2009	55384	T-Connector	5	2W	N/A	S6	4,10
YUKON XL DENALI	All	2001-2009	55384	T-Connector	5	2W	N/A	S6	4,10
GMC COMPACT PICKUP									
CANYON	w/Factory 7-way	2008-2009	55384	T-Connector	5	2W	N/A	T4	10
	w/o Factory 7-way	2004-2008	55510	T-Connector	10	3W	C1	T3	9
S-15 & SONOMA PICKUP	All	1998-2004	55359	T-Connector	5	2W	N/A	T3	
		1985-1997	55312	T-Connector	5	2W	N/A	T3	
	2-Door	1992-1994	55413	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S3	
GMC PICKUP FULL-SIZE									
C/K SERIES PICKUP	All, Except 88-91 Crew Cab	1988-2000	55315	T-Connector	5	2W	N/A	T3	
		1985-1987	55312	T-Connector	5	2W	N/A	T3	
		1973-1984	55311	T-Connector	5	2W	N/A	T3	
C/K SERIES PICKUP	Crew Cab, Old Body Style	1988-1991	55312	T-Connector	5	2W	N/A	T3	
SIERRA	Classic & New Body	1999-2008	55515	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	T3 OR T4	
	Classic & New Body w/Factory 7-way	2007-2009	55384	T-Connector	5	2W	N/A	T3	4,10
		2007-2007	56000	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T3	
	w/Factory 7-way	1999-2006	55384	T-Connector	5	2W	N/A	T3	4,10
		1999-2006	56000	5th Wheel / Gooseneck Adaptor Harness	45	N/A	N/A	T3	
SYCLONE		1991-1992	55312	T-Connector	5	2W	N/A	T3	
HONDA									
ACCORD	2-Door	2008-2008	55502	T-Connector	10	3W	C1	P3	9
	4-Door	2003-2008	55502	T-Connector	10	3W	C1	P3	9
	All	1994-2002	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	P3	9
CIVIC	4-Door	2006-2009	56011	T-Connector	20	3W	C1	P3,P4	9
CR-V	All	2007-2009	55106	T-Connector	30	3W	C1	S3	9
		1997-2006	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	S3	9
ELEMENT	All	2007-2008	56029	Replacement OEM Tow Package Wiring Harness (4-flat)	20	3W	C3	S8	
		2003-2004	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	S1,S2	9
FIT	All	2007-2009	56011	T-Connector	20	3W	C1	P3,P4	9
ODYSSEY	All	2005-2009	56007	T-Connector	15	3W	C3	S4	7
		1995-2004	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	S3	9
PASSPORT	All	1998-2002	55360	T-Connector	15	3W	C1	S1,S2	9
		1994-1997	55331	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C1	S1,S2	9
PILOT	All	2003-2008	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	S1,S2	9

2009 Curt Manufacturing T-Connector Application Guide

PRELUDE	All	2001-2002	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	P3,P4	9
RIDGELINE	All	2006-2009	55585	T-Connector	10	3W	C1	P1,P2	9
HUMMER									
H2	w/Factory 7-way	2003-2009	55384	T-Connector	5	2W	N/A	S6	4,10
H3	w/Factory 7-way	2006-2009	55384	T-Connector	5	2W	N/A	S6	4,10
H3T	w/Factory 7-way	2009-2009	55384	T-Connector	5	2W	N/A	S6	4,10
HYUNDAI									
AZERA	All	2006-2008	55400	T-Connector	20	3W	C1	P3,P4	
ELANTRA	All	2009-2009	55310	T-Connector	20	3W	C1	P3,P4	
ENTOURAGE	All	2007-2008	55503	T-Connector	25	3W	C1	S1,S2	9
GENESIS	All	2009-2009	56041	T-Connector	20	3W	C3	P3,P4	
SANTA FE	All	2007-2008	55538	T-Connector	20	3W	C1	S3,S4	
		2001-2006	55310	T-Connector	20	3W		S3,S4	9
TUCSON	All	2005-2008	55528	T-Connector	20	3W		S1,S2	9
VERACRUZ	All	2007-2007	56024	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W		S5	
INFINITI									
G35	All	2007-2008	56033	T-Connector	30	3W	C3	P3,P4	
G37	All	2009-2009	56033	T-Connector	30	3W	C3	P3,P4	
QX4	All	1997-2003	55361	T-Connector	20	3W	C1	S1,S2	9
QX56	w/Factory 7-way	2004-2009	55384	T-Connector	20	2W	N/A	S6	4,10
ISUZU									
AMIGO	All	1998-2000	55360	T-Connector	15	3W	C1	S1,S2	9
ASCENDER	w/Factory 7-way	2003-2008	55384	T-Connector	20	2W	N/A	S6	4,10
HOMBRE	All	1998-2000	55359	T-Connector	5	2W	N/A	T3	
		1996-1997	55312	T-Connector	5	2W	N/A	T3	
OASIS	All	1996-1999	55336	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C1	S3	9
PICKUP I-SERIES	All	2006-2008	55510	T-Connector	10	3W	C1	T3	9
PICKUP	All	1989-1995	55305	T-Connector	10	3W	C1	T1,T2	9
RODEO	All	1998-2004	55360	T-Connector	15	3W	C1	S1,S2	9
		1992-1997	55331	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C1	S1,S2	9
RODEO SPORT	All	2000-2003	55360	T-Connector	15	3W	C1	S1,S2	9
TROOPER	All	1992-2002	55339	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C1	S5	9
JEEP									
CHEROKEE	All	1997-2001	55354	T-Connector	20	3W	C1	S3	9
		1991-1996	55330	T-Connector	20	3W	C1	S3	
		1976-1982	55495	T-Connector	10	2W	N/A	S5	
COMMANDER	All	2006-2009	55414	T-Connector	15	3W	C1	S1,S2	9
COMPASS	All	2009-2009	56019	T-Connector	30	3W	C3	S1,S2	7
		2007-2008	55050	T-Connector	30	3W	C3	S1,S2	7
GRAND CHEROKEE	All	2007-2009	56009	T-Connector	15	2W	N/A	S1,S2	
		2005-2006	55451	T-Connector	20	3W	C1	S1,S2	9
		1999-2004	55369	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C3	S3,S4	9
		1994-1998	55349	T-Connector	25	3W	C3	S3,S4	7
		1993-1993	55348	T-Connector	25	3W	C3	S3,S4	9
GRAND CHEROKEE	w/Factory 7-way	2005-2009	55381	T-Connector	5	2W	N/A	S5	4,10
		2000-2004	55381	T-Connector	5	2W	N/A	S1,S2	4,10
	w/Tow Package	1995-1998	55260	T-Connector	25	3W	C3	S3	7
GRAND WAGONEER	All	1993-1993	55348	T-Connector	25	3W	C3	S3,S4	9
LIBERTY	All	2008-2009	55027	T-Connector	15	3W	C1	S1,S2	9
		2002-2007	55382	T-Connector	10	3W	C1	S1,S2	9
PATRIOT	All	2008-2009	56019	T-Connector	30	2W	C3	S1,S2	
		2007-2007	55050	T-Connector	30	3W	C3	P1,P2	7
TJ (Canada)	All	2005-2006	55363	T-Connector	10	2W	N/A	S5,S7	
		1998-2004	55363	T-Connector	10	2W	N/A	S5,S7	
		1997-1997	55356	T-Connector	10	2W	N/A	S5,S7	
		1991-1995	55356	T-Connector	10	2W	N/A	S5,S7	

2009 Curt Manufacturing T-Connector Application Guide

WAGONEER	All	1976-1982	55495	T-Connector	10	2W	N/A	S5		
WRANGLER	All	2007-2009	55124	T-Connector	10	2W	N/A	S1		
		2005-2006	55363	T-Connector	10	2W	N/A	S5,S7		
		1998-2004	55363	T-Connector	10	2W	N/A	S5,S7		
		1997-1997	55356	T-Connector	10	2W	N/A	S5,S7		
		1991-1995	55356	T-Connector	10	2W	N/A	S5,S7		
KIA										
AMANTI	All	2007-2008	56058	T-Connector	10	3W	C1	P3,P4		
BORREGO	w/Factory 7-way	2009-2009	55384	T-Connector	5	2W	N/A	T3	4,10	
RONDO	All	2007-2008	56023	T-Connector	30	3W	C2	S1,S2		
SEDONA	All	2006-2008	55503	T-Connector	25	3W	C1	S1,S2	9	
		2002-2005	55309	T-Connector	25	3W	C1	S1,S2	9	
SORENTO	All	2007-2008	56024	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C2	S5		
		2003-2006	55550	T-Connector	5	3W	C1	S7	9	
SPORTAGE	6 Cylinder Models Only	2005-2009	55529	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C1	S5	9	
		1998-2002	55371	T-Connector	20	3W	C1	S3,S4	9	
LEXUS										
LX 450	All	1996-1997	55357	T-Connector	5	3W	C1	S6	9	
LX 470	All	2001-2007	55245	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S6	11	
		1998-1999	55365	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C1	S6	9	
RX 300	All	2001-2003	55245	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S6	11	
RX 330	All	2003-2006	55563	T-Connector	20	3W	C1	S3	9	
LINCOLN										
AVIATOR	All	2003-2004	55344	T-Connector	10	2W	N/A	S1,S2		
		w/Tow Package	2003-2005	55251	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S7	11
LS	All	2000-2006	55373	T-Connector	20	3W	CL	P3,P4	7,8	
MKX	All	2007-2008	56014	T-Connector	10	2W	N/A	S1,S2		
NAVIGATOR	All	1998-2003	55344	T-Connector	10	2W	N/A	S1,S2		
		w/Factory 4-flat	2000-2002	55250	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S5	11
		1997-1999	55249	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S5	11	
MAZDA										
3	All	2004-2010	56011	T-Connector	20	3W	C1	P3,P4		
		2006-2007	56016	T-Connector	30	3W	C3	S3,S4		
5	All	2003-2008	55567	T-Connector	25	3W	C3	P3,P4	7	
		5-Dr Hatchback	2004-2008	55567	T-Connector	25	3W	C3	P3,P4	7
6	All	1994-2008	55325	T-Connector	5	3W	C1	T1,T2	9	
		1985-1993	55304	T-Connector	5	3W	C1	T1,T2	9	
		w-Factory 4-flat	1998-2001	55241	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	T3	11
CX-7	All	2007-2008	55593	T-Connector	25	3W	C3	S4	9	
CX-9	All	2007-2009	56016	T-Connector	30	3W	C3	S3,S4		
MPV	All	2000-2006	56010	T-Connector	20	3W	C1	S3,S4	9	
NAVAJO	All	1991-1994	55324	T-Connector	20	2W	N/A	S1		
TRIBUTE	All	2008-2009	56014	T-Connector	10	2W	N/A	S1,S2		
		2005-2007	55568	T-Connector	10	3W	C1	S1,S2	9	
		2001-2003	55343	T-Connector	10	3W	C1	S1,S2	9	
TRIBUTE	w/Tow Package	2001-2004	55255	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S3	11	
MERCURY										
GRAND MARQUIS	All	1992-1997	55326	T-Connector	20	2W	N/A	P3,P4		
MARINER	All	2005-2009	56014	T-Connector	10	2W	N/A	S1,S2		
MONTEREY	All	2004-2007	56073	Replacement OEM Tow Package Wiring Harness (4-flat)	5	2W	N/A	S6		
		2004-2007	55545-RK	T-Connector		N/A	N/A	N/A		
MOUNTAINEER	All	2002-2003	55344	T-Connector	10	2W	N/A	S1,S2		
		1997-2001	55345	T-Connector	25	3W	C3	S1,S2	7	
		w/Factory 4-flat	2002-2005	55251	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S7	11
SABLE	All	1997-2001	55241	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S5	11	
		2000-2003	55375	T-Connector	10	2W	N/A	P3,P4		

3/26/09

		1996-1999	55333	T-Connector	10	3W	C1	P3,P4	9
TRACER	4-Door	1992-1995	55351	T-Connector	10	2W	N/A	P3,P4	
VILLAGER	All	1997-1999	55344	T-Connector	10	2W	N/A	P1,P2	
		1998-1998	55362	T-Connector	20	3W	C1	S1,S2	9
MINI									
ENDEAVOR	All	2003-2008	56039	Replacement OEM Tow Package Wiring Harness (4-flat)	15	3W	C3	S3	
MONTERO	All	2001-2007	55380	T-Connector	20	3W	C1	S1,S2	
		1992-2000	55464	T-Connector	20	3W	C1	S1,S2	
OUTLANDER	All	2003-2006	55565	T-Connector	25	3W	C1	S3,S4	
RAIDER	All	2006-2007	55323	T-Connector	10	2W	N/A	T1,T2	
NISSAN									
ALTIMA	All	2007-2008	56022	T-Connector	30	3W	C2	P3,P4	
		1998-2001	55361	T-Connector	20	3W	C1	P3,P4	9
FRONTIER	w/Factory Tow Package	2005-2008	55441	Replacement OEM Tow Package Wiring Harness (4-flat)	5	2W	N/A	T3	
	All	1998-2003	55362	T-Connector	5	3W	C1	T5	9
MAXIMA	All	2004-2009	56022	T-Connector	30	3W	C2	P3,P4	
MURANO	All	2003-2005	55571	T-Connector	25	3W	C3	S3,S4	7
PATHFINDER	w/Factory Tow Package	2005-2008	55441	Replacement OEM Tow Package Wiring Harness (4-flat)	5	2W	N/A	S5	
	All	1996-2004	55361	T-Connector	20	3W	C1	S1,S2	9
		1987-1995	55353	T-Connector	10	3W	C1	S1,S2	9
PATHFINDER ARMADA	w/Factory 7-way	2004-2008	55384	T-Connector	5	2W	N/A	S6	4,10
PICKUP	All	1986.5-1997	55353	T-Connector	10	3W	C1	T1,T2	9
QUEST	All	2003-2007	55570	T-Connector	10	3W	C1	S1,S2	7
		1998-1998	55362	T-Connector	20	3W	C1	S1,S2	9
ROGUE	All	2008-2009	56033	Replacement OEM Tow Package Wiring Harness (4-flat)	30	3W	C3	S3,S4	
SENTRA	All	2007-2008	56022	T-Connector	30	3W	C2	P3,P4	
TITAN	w/Factory 7-way	2004-2008	55384	T-Connector	5	2W	N/A	T3	4,10
		2004-2008	56000	5th Wheel / Gooseneck Adaptor Harness	45	N/A	NA	T3	
VERSA	All	2007-2008	56021	T-Connector	30	3W	C2	P3,P4	
XTERRA	w/Factory Tow Package	2005-2008	55441	Replacement OEM Tow Package Wiring Harness (4-flat)	5	2W	N/A	S5	
		2000-2004	55244	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S7	11
OLDSMOBILE									
BRAVADA	w/Factory 7-way	2002-2004	55384	T-Connector	15	2W	N/A	S6	4,10
	All	1995-2001	55411	T-Connector	15	2W	N/A	S7	
CUSTOM CRUISER WAGON	All	1991-1992	55352	T-Connector	10	2W	N/A	P3,P4	
SILHOUETTE	All	1997-2004	55355	T-Connector	10	3W	C1	S3	9
		1993-1996	55337	T-Connector	20	2W	N/A	S1,S2	9
PLYMOUTH									
GRAND VOYAGER	All	1996-2000	55334	T-Connector	20	3W	C1	S1,S2	9
		1991-1995	55323	T-Connector	10	2W	N/A	S1,S2	
TRAILDUSTER	All	1986-1993	55317	T-Connector	5	2W	N/A	S5,S7	
VOYAGER	All	1996-2000	55334	T-Connector	20	3W	C1	S1,S2	9
		1991-1995	55323	T-Connector	10	2W	N/A	S1,S2	
		1989-1990	55493	T-Connector	10	?	?	S1,S2	
PONTIAC									
AZTEK	All	2001-2005	55383	T-Connector	20	2W	N/A	S1,S2	
G5	2-Door	2007-2009	55432	T-Connector	10	2W	NA	P1,P2	
	4-Door	2007-2009	55434	T-Connector	10	2W	NA	P1,P2	
	GT (2-Door)	2007-2009	55432	T-Connector	10	2W	NA	P1,P2	
G5 PURSUIT Canada Only	2-Door	2005-2009	55432	T-Connector	10	2W	NA	P1,P2	
	4-Door	2005-2009	55434	T-Connector	10	2W	NA	P1,P2	
	GT (2-Door)	2005-2009	55432	T-Connector	10	2W	NA	P1,P2	
G6	All	2005-2009	56013	T-Connector	20	2W	N/A	P1,P2	
MONTANA SV6	All	2005-2006	55536	T-Connector	15	2W	N/A	S1,S2	
MONTANA	All	1999-2005	55355	T-Connector	10	3W	C1	S3	9
TORRENT	All	2007-2008	56012	Replacement OEM Tow Package Wiring Harness (4-flat)	15	2W	N/A	S3	

2009 Curt Manufacturing T-Connector Application Guide

TRANS SPORT VAN	All Including Montana	2006-2006	55560	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C3	S3	9
		1997-1998	55355	T-Connector	10	3W	C1	S3	9
		1993-1996	55337	T-Connector	20	2W	N/A	S1,S2	9
VIBE	All	2009-2009	56035	T-Connector	30	3W	C3	P3,P4	
		2003-2008	55057	T-Connector	25	3W	C3	?	
SAAB									
9-7X	w/Factory 7-way	2005-2008	55384	T-Connector	5	2W	N/A	S6	4,10
SATURN									
AURA	All	2007-2008	56017	T-Connector	20	3W	C1	P1,P2	
ION	All	2003-2007	56036	T-Connector	10	3W	C1	P1,P2	
OUTLOOK	All	2007-2009	56025	T-Connector	15	2W	N/A	S1,S2	
	w/Factory 7-way	2007-2009	55384	T-Connector	5	2W	N/A	S5	4,10
RELAY	All	2005-2007	55536	T-Connector	15	2W	N/A	S1,S2	
VUE	All	2008-2009	56026	T-Connector	30	3W	C3	S3,S4	
		2002-2007	56018	T-Connector	15	3W	C1	S1,S2	
SCION									
XB	All	2008-2009	56062	T-Connector	45	3W	C3	S3,S4	
		2004-2007	56030	T-Connector	20	3W	C1	S1,S2	
SUBARU									
B9 TRIBECA	All	2006-2008	55370	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C3	S8	7
IMPREZA	Sedan	2008-2008	56061	T-Connector	45	3W	C3	P3,P4	
FORESTER	All	2009-2009	56040	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C3	S8	
		1998-2008	55370	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C3	S4	7
LEGACY WAGON	Outback Only	1996-1999	55370	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C3	P3,P4	7
OUTBACK WAGON	All Except Sport	2000-2008	55370	Replacement OEM Tow Package Wiring Harness (4-flat)	10	3W	C3	P3,P4	7
SUZUKI									
GRAND VITARA	All	2006-2008	56002	T-Connector	20	3W	C1	S3,S4	9
		1999-2005	55372	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C1	S3	9
SX4	All	2007-2007	56002	T-Connector	20	3W	C1	S3,S4	9
VITARA	All	1999-2005	55372	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C1	S3	9
XL-7	All	2007-2008	56012	Replacement OEM Tow Package Wiring Harness (4-flat)	15	2W	N/A	S4	
		2001-2006	55372	T-Connector	5	3W	C1	S3	9
TOYOTA									
4RUNNER	All	1996-2002	55341	T-Connector	20	3W	C1	S3,S4	
		2001-2002	55245	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S3,S4	11
CAMRY	4-Door Except Hybrid	2007-2009	55567	T-Connector	25	3W	C3	P3,P4	7
	4-Door	2002-2006	55308	T-Connector	5	3W	C1	P3,P4	9
		1997-2001	55358	T-Connector	5	3W	C1	P3,P4	9
COROLLA	All	2003-2009	55542	T-Connector	15	3W	C1	P3,P4	9
ECHO	All	2000-2002	55522	T-Connector	20	3W	C1	P3,P4	9
FJ CRUISER	All	2007-2009	55567	T-Connector	25	3W	C3	S3,S4	7
HIGHLANDER	All	2008-2008	56034	Replacement OEM Tow Package Wiring Harness (4-flat)	30	3W	C3	S3,S4	
	All Except Hybrid	2001-2007	55400	T-Connector	20	3W	C1	S3,S4	2
	All	2001-2003	55245	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S6	11
HIGHLANDER	w/Tow prep package	2008-2008	56042	Replacement OEM Tow Package Wiring Harness (4-flat)	20	2W	N/A	S3	
LANDCRUISER	All	2001-2002	55245	Replacement OEM Tow Package Wiring Harness (4-flat)	5	N/A	N/A	S6	11
		1998-1999	55365	Replacement OEM Tow Package Wiring Harness (4-flat)	5	3W	C1	S6	9
		1996-1997	55357	T-Connector	5	3W	C3	S6	9
MATRIX	All	2009-2009	56035	T-Connector	30	3W	C3	P3,P4	
		2003-2007	55522	T-Connector	20	3W	C1	S3,S4	
		2001-2005	55307	T-Connector	20	3W	C1	S3,S4	9
PICKUP	All Except T-100	1989-1995	55379	T-Connector	10	3W	C1	T1,T2	9
RAV4	All	2006-2009	55113	T-Connector	25	3W	C3	S3,S4	
		2001-2005	55307	T-Connector	20	3W	C1	S3,S4	9
SCION XB	All	1996-2000	55486	T-Connector	20	3W	C1	S3,S4	9
		2008-2009	56062	T-Connector	45	3W	C3	S3,S4	
		2004-2007	56030	T-Connector	20	3W	C1	S1,S2	

2009 Curt Manufacturing T-Connector Application Guide

SEQUOIA	All	2001-2002	55246	Replacement OEM Tow Package Wiring Harness (4-flat)	5	2W	N/A	S7	11
SIENNA	All	2004-2009	55580	T-Connector	10	3W	C1	S1,S2	9
		1998-2003	55418	T-Connector	10	3W	C1	S3,S4	9
T-100	All	1993-1998	55513	T-Connector	10	3W	C1	T3,T5	9
TACOMA	All	2005-2006	55513	T-Connector	10	3W	C1	T1,T2	9
		1995.5-2004	55379	T-Connector	10	3W	C1	T1,T2	9
TUNDRA	All	2001-2002	55378	T-Connector	10	3W	C5	T3	7
		2000-2000	55367	T-Connector	10	3W	C3	T3	7

CONVERTER TYPE CODES	OLD WIRING CODES
C1 - Converter	1 = Standard 2-wire system
C2 - Converter, Circuit Protected	2 = 3-wire system, requires converter
C3 - Converter, Powered	3 = May be 2 or 3-wire system
C4 - Converter Circuit Protected & Powered	4 = Adds 4-way to OEM 7-way
C5 - Converter, Circuit Protected & Powered w/ Relay	5 = Powered converter required
CL - Converter, Low-Side Switching	6 = Powered converter recommended
	7 = Powered converter included
ELECTRICAL SYSTEM CODES	8 = Low-side switching system
2W - Standard 2-wire system	9 = Circuit protected converter included
3W - 3-wire system	10 = W/OEM Tow Package
MP - Multiplex system	11 = OEM replacement end or socket
	12 = Upgrade OEM to 7-way w/ relays
WIRE LOCATION CODES	13 = N/A, see your new car dealer
SEE DIAGRAM ON PAGE 80 OF THE 2008 CURT CATALOG OR AT WWW.CURTMFG.COM	14 = Upgrade OEM to 6-way w/ relays
	15 = OEM plug to 7RV & 4-flat
	16 = OEM plug to 6-round & 4 flat