

SUGGESTED SPREADER SETTINGS



SGN 100	# OF PRODUCT PER 1000 SQ. FT.	# OF PRODUCT PER ACRE	SCOTTS R8	ACCUPRO	LESCO ROTARY	LESCO	SPYKER 24	PRIZELAWN CB	EARTHWAY 2400	LELY	VICON
	2 LBS	87 LBS	H	I	F	9	2.25	2.75	12	3	17
	3 LBS	130 LBS	H-I	I-J	F-G	10.5	3.25	3.25	12.5	3.75	21
	4 LBS	174 LBS	I	J	G	12	3.5	3.75	13	4.5	25
	5 LBS	218 LBS	J	K	H	14	3.75	4	14	5	28
	6 LBS	261 LBS	K	L	H-I	16	4	4.5	15	5.5	30
	8 LBS	348 LBS	M	N	J-K	20	4.5	5	17	6.75	37
SGN 150	# OF PRODUCT PER 1000 SQ. FT.	# OF PRODUCT PER ACRE	SCOTTS R8	ACCUPRO	LESCO	LESCO	SPYKER 24	PRIZELAWN CB	EARTHWAY 2400	LELY	VICON
	2 LBS	87 LBS	I	J	G	12	3.5	3.75	13	4	22
	3 LBS	130 LBS	J	J-K	G-H	13.5	3.75	4.25	14	4.5	25
	4 LBS	174 LBS	K	L	H	15	4	4.5	15	5.25	29
	5 LBS	218 LBS	L	M	H-J	17	4.25	4.75	16	5.5	31
	6 LBS	261 LBS	M	N	J-K	20	4.5	5	17	6	33
	8 LBS	348 LBS	O	P	M	24	5	5.5	19	7	39
SGN 220	# OF PRODUCT PER 1000 SQ. FT.	# OF PRODUCT PER ACRE	SCOTTS R8	ACCUPRO	LESCO	LESCO	SPYKER 24	PRIZELAWN CB	EARTHWAY 2400	LELY	VICON
	3 LBS	130 LBS	K	K-L	H-J	17	4	4.5	15.5	3.75	30
	4 LBS	174 LBS	L	M	J-K	20	4.5	5	17	6.25	36
	5 LBS	218 LBS	M	N	K	21	4.5	5	17.5	6.5	37
	6 LBS	261 LBS	N	O	L	22	4.75	5.25	18	7	39
	8 LBS	348 LBS	P	Q	N	26	5.5	6	20	8	44



Notice: These are approximate settings, age and condition of spreader can affect setting - always calibrate your spreader before using. Instructions for how to calibrate your spreader can be found on our website.

