



## DROP SPREADERS

**Notice:** These are approximate settings, age and condition of spreader can affect setting - always calibrate your spreader before using. Instructions for how to calibrate your spreader can be found on our website.

SPREADER NAME	MENARD PREMIUM								
	26-2-3 or 26-0-3 Crabgrass Preventer	28-2-3 or 28-0-3 Weed & Feed	30-2-3 or 30-0-3 Lawn Food	29-0-4 Lawn Food with Insect Control	23-2-10 or 23-0-10 Winterizer & Weed Control	22-3-10 or 22-0-10 Winterizer	15-23-10 Starter	Menards Premium Grub Control	Menards Premium Insect Control
AgriFab	4	4	4	4	4	4	4	6.5	6
LawnCrafters	4	4	4	4	4	4	4	6.5	6
Lowes	4	4	4	4	4	4	4	6.5	6
Craftsman	4	4	4	4	4	4	4	6.5	6
Stanley	4	4	4	4	4	4	4	6.5	6
TSC	4	4	4	4	4	4	4	6.5	6
Ames	2.5	2.5	2.5	2.5	2.5	2.5	2.5	3	3
Ames Deluxe 2-1	1.5	1.5	1.5	1.5	1.5	1.5	1.5	2	2
Agway	9.5	9.5	9.5	9.5	9.5	9.5	9.5	10	10
Earthway 735	9.5	9.5	9.5	9.5	9.5	9.5	9.5	10	10
Earthway EV-N-Spread	9.5	9.5	9.5	9.5	9.5	9.5	9.5	10	10
Fertilome	9.5	9.5	9.5	9.5	9.5	9.5	9.5	10	10
Green Thumb	9.5	9.5	9.5	9.5	9.5	9.5	9.5	10	10
Greenview	9.5	9.5	9.5	9.5	9.5	9.5	9.5	10	10
Greenview Jet Spread	9.5	9.5	9.5	9.5	9.5	9.5	9.5	10	10
Pennington	9.5	9.5	9.5	9.5	9.5	9.5	9.5	10	10
Ortho	5	5	5	5	5	5	5	5	5
Green Line	1.5	1.5	1.5	1.5	1.5	1.5	1.5	2	2.5
Cyclone	6.5	6.5	7	7	6.5	6.5	6.5	7	7.5
E-Z Spread	1.5	1.5	1.5	1.5	1.5	1.5	1.5	2	2.5
Precision Pro	1.5	1.5	1.5	1.5	1.5	1.5	1.5	2	2.5
Red Devil old (0-12)	6.5	6.5	7	7	6.5	6.5	6.5	7.5	8
Red Devil new (0-5)	1.5	1.5	1.5	1.5	1.5	1.5	1.5	2	2.5
Sta-Green	1.5	1.5	1.5	1.5	1.5	1.5	1.5	2	2.5
Vigoro	1.5	1.5	1.5	1.5	1.5	1.5	1.5	2	2.5
Ace	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5	5.5
Quaker	5	5	5	5	5	5	5	5	5
EZ Grow	5	5	5	5	5	5	5	5	5
Scotts Accu Green 1000	6	6	6	6	6	6	6	7	7
Scotts Accu Green 2000	6	6	6	6	6	6	6	7	7
Scotts Accu Green 3000	6	6	6	6	6	6	6	7	7
Scotts Accu Green AG-3	3.25	3.25	3.25	3.25	3.25	3.25	3.25	4	4
Scotts Drop	6	6	6	6	6	6	6	7	7
Scotts Even Green	7.25	7.25	7.5	7.25	7.25	7.25	7.25	8	7
Scotts (old)	D	D	D	D	D	D	D	E	E
Precision Green PF-4	6.25	6.25	6.25	6.25	6.25	6.25	6.25	7	7
Plant Mate	1.7	1.7	1.7	1.7	1.7	1.7	1.7	2.2	2.2
Taylor	1.7	1.7	1.7	1.7	1.7	1.7	1.7	2.2	2.2

**Spreader Not Listed - Setting Tip:** Set spreader at 1/4 to 1/3 of the dial as a starting point. This is just a guide always calibrate spreader.